#### SUPPLEMENTARY MACHINE SERVICE BULLETIN 108-B

SUBJECT: Price list for KASC model

parts and assemblies

DATE: October 29, 1931

#### TO ALL OFFICES:

Effective November 1, 1931 field offices will be billed for all repair parts and assemblies for C and E models on the regular basis of list, less 35%.

Charges are to be made for repair service to customers' machines of these models which are out of guarantee.

We are attaching a complete parts and assembly list, pages 1 to 8 inclusive, which includes the prices of this material.

These pages supplement pages 1 to 7 in Machine Service Bulletin #108, WHICH ARE TO BE DESTROYED, AND PAGES 1 TO 8 SUBSTITUTED IN THEIR PLACE.

FMS:MG

General Service Manager

Part No.	Description Group Plate Price	9
209-C 562 618-C 6181-C 626-C 628-C 6291-C	Selecting Arm for Five Teeth Selecting Gear 8 26 .25 Stud for 510 in 536 (not shown) .05 Clamping Strip on Rear Cover Case 16 Pl. 4 24 .15 Clamping Strip on Rear Cover Case 20 Pl. 4 24 .15 Repeat and Non-repeat Keystem 11 29 .10 Keyboard clearing keystem 8 26 .10 Bracket for Plus and Minus Lock Slide	
692½-C 694¼-C 698-C 698½-C 725-C 735-C 735-1/16C 735-7/8C 743-1/8C	Sun gear pinion - 40 and 50 cycle 9 27 .85 Locking collar for 701 10 27 .15	
771½-C 775-C	Screw for front end of sub plate on key shift  Motor Bracket  11 28 .05  9 27 7.50	
874-C 898-C 912 920 x 1 921 <del>1</del> 922 940 941 943	Guide Stud for KD carriage lift bar.  Right end Insulating spacer for start & stop switch Terminal for 781 x 2 spring Friction washer (not shown) Clearing lock (See Bulletin 112) Terminal for hammer spring (not shown) Guide nut for slide bars on keyboard Bushing for locator arm (not shown) Spacing washer for front shift lock slide (See Bulletin 108-A).05	
945 x 1 946 x 1 947	Lock nut (not shown) .05 Spindle for middle clear clutch (not shown) .45 Special stud for clearing lock bracket	
948	(See Bulletin 112) .05 Spring stud for lower clearing lever (See Bulletin 108-A).05	
	Spring stud for middle clearing lever (See Bulletin 108-A).05	
9484	Spring stud for upper clearing lever (See Bulletin 108-A).05	
949	Spring stud in clutch unit for clearing levers (See Bulletin 108-A).10 Screw for fastening bell and zero key brackets	
959 959 <del>1</del>	(not shown) .05 Spacing stud for bracket on R.H. side frame 7 26 .15 Support stud between bracket and cover case	
960 961 962 963	R.H. side  R.H. side  Latch pin stud on key shift  Spring pin for arm on latch pin key shift  Latch pin for key shift  Pivot stud for release latch on key shift  11 28 .30  26 .15  28 .05  11 28 .30  29 .05	

Part No	<u>Description</u>	Group	Plate	Price
964 965	Pin for release latch on operating arm Pivot stud on operating arm for release	11	29	.05
966	latch Pivot stud for resetting arm	11 (11	29 28	.10
967	Pivot pin for latch on front shutter	(11	29	10
968	shift bar Pin for driving front and shutter shift	8	26	.10
969	bar - key shift Spring stud for latch on front shift	8	26	.05
970	bar Spring stud on sub plate for release	8	26	.05
978	operating arm Guide screw for front end of shift lock	11	28	.05
978 <del>1</del>	slide (See Bul Guide screw for rear end of shift lock	letin	108A)	.10
0104	slide (See Bul	letin	108A)	.10
982	Spring for lock bars	11	28	.05
983	Spring for latch pin	11	28	.05
984	Spring for release latch	11	29	.05
985	Spring for rocker locator	11	29	.05
	Spring for hammer	11	28	.10
987	Spring for resetting arm	11	29	.05
988	Spring for keys	11	29	.10
989 1026	Spring for release operating arm Bell crank for yoke operating on key	11	29	.05
1029	shift Spring bracket for rocker spring on	11	28	.15
1025	key shift	3	24	.10
1030	Operating piece for R.H. shift lock bar	ī	23	.15
1031	Connecting link for locking clear out			
	keys	3	24	.25
1033	Guide blank for key shift toggle links	11	29	.10
1034	Toggle link for key shift	11	29	.10
1035	Idle gears	9	27	.50
10354	Idler gear	9	27	.35
1036	Drive gear	9	27	.40
1039	Friction washer for eccentric studs on clearing levers	6	25	.05
1040	Hubs for clear out keys locking bar R.H. side	7	26	
1041	Pivot hub for upper cross over lever R.H. side	6	25	.10
1042	Pivot hub for middle and lower cross over			
1043	lever Pivot hub for middle and lower clear key	6	25	.05
1044	lever Pivot stud for upper clear key lever	6 (6	25 25	.05
	The state of the s	(7	26	
1046	Spacing collar for key shift toggle link L.H.	11	29	.05
10464	Spacing collar for key shift toggle link			
	R.H.	11	29	.05

Part No	. <u>Description</u>	Group	Plate	Price
1047	Bearing for latch pin pulling arm on key shift	11	28	.05
1048	L.H. bearing for rocker shaft on sub- plate		28	
1049	Hammer bearing on key shift Stud for locking pieces	11 11 7	28 26	.05
1051	Spring pin for locking slide spring	(6	25	.05
1052	Screw for clearing keys guide blank	(6	25 26	.05
1053	Pivot stud for cross over levers on R.H. frame	2	23	.25
1054	Pivot screw for cross over levers	(2)	23 25	.20
1055	Screw for stop and start switch Pivot stud for fibre collar operating	5	24	.05
1057	contact spring strips Stud on arm for contact roller	6	25 25	.05
1058	Clear key lever eccentric stop	(6	25 26	.15
1059	Stud for key latches Pivot screw for clear key levers	7	26 25	.05
1062	Pivot stud for lock bars on key shift Pin for top of rocker on key shift	11	28	.10
1067	shaft Adjustment stud for stroke of shift	11	29	.05
1068	keys Spring stud for key shift. R.H. key	11 11	29 29	.15
1070	Pivot stud for connecting latch cam setting bars	8	26	.05
1071	Screw for back and top of sub-plate on key shift	11	28	.10
1072	Stop pin for resetting arm key shift Spring stud on sub-plate for resetting	īī	28	.05
1074	arm Spring stud on release latch for key	11	28	.05
1075	shift Spring stud on resetting arm for key	11	29	.05
1076	shift Pivot stud for end of R.H. shift set-	11	29	.05
1077	ting bar Pivot stud for hammer latch pin puller	11 4	29 28	.05
1078	Driving pin for latch link on cross over tube	3	24	.15
1079	Driving pin for latch link arm on cross over tube	3	24	.15
1080	Spring for normal setting latch Spring for top of resetting arm and top	8	26	.05
	of release arm	11	29	.05

PART NO	DESCRIPTION G	ROUP	PLATE	PRICE
1107	Cover case on right side of carriage Rear shutter shift bar	1 8	23 26	.55
11081	Front shutter shift bar	8	26	.50
1114	Spring arm for latch pin on key shift Connecting latch between front and	11	28	.10
11261	back cam setting bar Front end of plus and minus key lock	8	26	.30
	slide (See Bull			.30
1127	Plus and minus lock blank (See Bull Spacing washer for rear end of shift	Letin	108A)	.20
1130	key lock slide (See Bul Stop for locator arm		108A) t shown)	.05
1137	Front spacing collar for sub-plate	11	28	.10
1138	Top and rear spacing collar for sub- plate	11	28	.15
1139	Roller for machine stopping lever	10	27	.05
1140	Spacing washer on end of hammer link Rocker for key shift toggle links	11	28 29	.05
1148 x 1	Spacing sleeve for latch on front shutter shift bar	8	26	.05
1149	Bearing for latch pin on key shift	11	28	.25
1155	Driving pin for latch release and cam setting on key shift	11	28	.05
1156	Pivot pin for over-carry trip lifter	11	28	
1157	on key shift Driving pin for lifter of bumper key			.05
1158	shift Driving pin for over-carry trip lift-	11	28	.05
	er and yoke bell crank	11	28	.05
1159	Driving pin in cycle stopping arm for key shift	10	27	.15
1160	Screw stud for hammer link end Pivot stud for hammer link on key	11	28	.10
	shift	11	28	.05
1162	Spring stud on hammer for key shift Spring stud in sub-plate for hammer	11	28	.05
	spring	11	28	.05
1164	Roller stud for machine stopping levers	10	27	.10
1166	Driving stud for hammer latch lifter Spacing of button for locking bars	11	29	.05
	on key shift	11	28	.10
1168	Stud on arm and extension on inside of left side frame Rear	3	24	.05
1169	Pivot stud for repeat and non-repeat lever	11	29	.05
1170	Pivot stud for key shift toggle link			
11704	L.H. Pivot stud for key shift toggle link	11	29	.05
4	R.H.	11	29	.05

Part No.	Description	Group	Plate	Price
1171	Adjusting stud for clearing lock (See	Bulletin	112)	.10
1172	Pivot stud for hammer on key shift	11	28	.05
1173	Spring stud for key shift	ii	29	.05
1174	Guide stud for top of resetting arm.			
	Key shift	11	29	.10
1178-C	Linoleum strip for front and left side			
	cover case	4	24	.15
1187	Rubber key top for division lever (not	shown)		.05
1196	Front Transfer (See Bulletin 116)		78	.10
1280	Pin in carriage lock latch L.H.	1	23	.05
1329-C	Strip for holding linoleum	4	24	.10
1353-C	Stop for coupling lever	10	27	.20
1512	Support bracket	9	27	.15
15131	Flexible nose for lower & upper dial			
	clearing levers	6	25	.15
15144	Flexible nose for lower dial clearing			
	lever	6	25	.20
15151	Flexible nose for upper dial clearing			
	lever	6	25	.20
15174	Middle clear key lever	6	25	.35
15184	Lower clear key lever	6	25	.35
15191	Upper clear key lever	6	25	.40
1520	Bearing plate	9	27	1.25
1524	Washer under locking pieces	7	26	.05
1525	Guide for clear out keys	7	26	.25
1526	Clear key locking bar guide	6	25	.15
1527	Clearing keys locking bar	6	25	.35
1529	Key latch for lower & middle keys	7	26	.15
15291	Key latch for lower & middle keys	7	26	.15
1530	Key latch for upper keys	7	26	.15
1532	Guide bracket for clear key levers	6	25	.15
1535	Clutch gear	9	27	.45
15351	Idler gears Left side	9	27	1.00
	Drive gear	9	27	.35
15364	Idler gear	9	27	.60
1538	Driving hub for hinge rod. Left side		23	.50
1540	Driving gear for upper dial clutch	9	27	.90
15404	Idler gear Clutch gears	9	27	.35
		9	27	.45
1042	Roller on upper clearing lever	6	25	.05
	Spacing collar	9	27	.05
1544 1/0	Idler gear on carriage. R.H. end	Т	23	.25
1040	Roller on stud of arm on right side of cross over tube	7	24	05
1546	Locating arm roller	3	24	.05
1552	Shaft for clutch housings	9	27	.05
1553	Drive shaft. Left side	9	27	.10
1554	Stud to hold bearing plate & cover.	9	ומ	.00
	R.H. side of carriage	1	23	.15
		The state of the s	20	

Part No.	Description	Group	Plate	Price
1554 <del>1</del> 1555 1556	Stud to hold guide stud & cover on right end of carriage Pivot stud for locator arm Pivot stud for cam roller	1 9	23 27 27	.20 .05
1557	Spacing rod for 3/32" bearing plate. Le side	ft 9	27	.50
1560 1561 1563	Dowels for bearing plates on carriage. Right and Left Screw Stud for roller on upper and lower clear	1 9	23 27	.05
1564	ing lever Driving pin for driving hub for hinge ro	6	25 23 24	.05
1565 1566 1567 1568	Stud for idler gear in bearing plate on right end of carriage Stud for idler gears on left side Pivot stud for idler gears Drive stud	1 9 9 (9 (3	23 27 27 27	.05 .05 .10
1569 1570 1571	Stud for idler gears Locking screws for clearing levers Eccentric stud for clearing levers (left	96	24 27 25	.10
1572 1574 1575 1576 1577 1582 1583	side) Support post for clearing levers Stud on clear out keystems Spring stud for L.H. shift key in bracker Stop pin for key shift toggle links Casting for rear cover case Spring for hinge locator Spring for repeat & non-repeat key Friction spring for middle clear clutch (See Bulletin 112)	6 2 8 t 11 11 4 9	25 23 26 29 29 24 27 29	.10 .25 .05 .05 .10 1.75 .05 .05
	Assemblies			
6-0-0 6-10-0 6-65-0 6-66-0 6-68-0 6-68\frac{1}{2}-0	Carriage lift knob R.H. side frame L.H. side frame L.H. cover case section R.H.cover case Rear cover case section Rear cover case section Over-carry release latch, support lever, etc. Cycle stopping arm spring with terminals	1 2 2 4 4 4 4 10 (not	23 23 24 24 24 24 24 27 shown)	.65 5.50 6.00 6.25 5.75 7.25 7.25
7-76-D 9-1 9-2 9-4	Guide blank for 731-1/8D stud and washer Hinge rod driving gear & locator cam Oil shield Locator arm for hinge rod cam	10 1 9 9	27 23 27 27	.20 .70 .45

Assembly Number	Description	Group	Plate	Price
9-5	Clutch assembly for upper & lower dials		27	1.50
9-6	Lower dial clutch assembly	9	27	1.95
9-61	Hub for lower dial clutch	9	27	1.15
9-7	Upper dial clutch assembly	9	27	1.95
9-71	Hub for upper dial clutch	9	27	1.35
9-9	Idler gear assembly Switch operating lever	9 9	27	
	Bracket assembly on R.H. side	6	25	.65
9-11 x 1	Cross over lever for upper and lower dials	6		
9-11½ x1	Cross over lever for upper and lower		25	1.65
0_19 = 1	dials 20 pl.	6	25	1.95
9-121 x1	Cross over lever for lower dials Cross over lever for lower dials 20 pl.	6	25	
9-12	Nose and roller for lower dial clutch	6	25	2.15
9-13 x 1	Cross over lever for upper dials	6	25 25	.30
$9-13\frac{1}{2}$ xl	Cross over lever for upper dials 20 pl.	6	25	
9-134	Nose and roller for upper dial clutch	6	25	.30
9-14 x 1	Clear out key assembly, lower and middle			
0 75 7	keys	8	26	
9-15 X T	Upper clear out key assembly	8	26	.35
9-161	Locking bar lever assembly 20 pl.	3	24	.75
9-17	Rocker Arm	2	29	
9-18	Resetting arm and latch	11		
9-18 1/8	Latch release arm (AS)		shown)	
9-184	Resetting arm	11	29	.25
	Front shutter shift bar & connecting link	8	26	1.00
9-21	Lock bar for L.H. shift	11	28	.60
9-214	Lock bar for R.H. shift	11	28	.60
9-22	Latch on front shutter shift bar	8	26	.40
9-231	Cam setting slide Release latch operating arm (F.S.)		29	
9-23 1/8	Cam sitting slide with pin (F.S.)	11	29	.45
9-24	Hammer and hammer link	77	28	.35
9-24 1/8	Link (F.S.)		28	
9-244	Link (F.S.)	11	28	.35
9-25	Sub-plate assembly	11	28	2.75
9-254	Hammer spring with terminals	(not	shown)	.20
9-20	Upper bracket and shift keys Left shift key	11	29	2.35
9-27 1/8	L.H. Toggle link & spool (F.S.)	11	29	.45
9-274	Right shift key	11	29	.15
9-28	Tower breaket	77	00	.55
9-29	L.H. key shift key top R.H. key shift key top Lifter for flexible over-carry lever	11	29	.35
9-294	R.H. key shift key top	11	29	.35
9-30	Lifter for flexible over-carry lever	11	29	.25
9-01	Operating arm for machine stopping lever	11	29	.25
3-02 X I	Guide bracket for shift bar	11	29	.55

Assembly Number	Description	Group	Plate	Price
9-33 9-34 9-36	Hammer latch pin puller Lock for clear levers (See Bulletin 112)	11	28	.30
9-36A	Front shift lock slide for C model (See Bulletin 108A) Front and end shift lock slide for E	1)		.35
9-37 xl	model (See Bulletin 108A Safety latch on front cam shift bar	.)		.30
9-40	(See Bulletin 108A Front arm for latch link	3	24	.35
9-51	Assembly of gear on clearing crank shaft	1	23	.90
9-52	Assembly of gear on R.H. end of hinge rod	1	23	1.40
9-52½ 9-54	Assembly of gear on R.H. end of hinge rod 20 pl.	1	23	1.50
9-544	L.H. hinge rod bearing plate R.H. hinge rod bearing plate	i	23 23	.50
9-93 9-94	Release latch for key shift (F.S.) Release latch and arm for key shift	11	29	.20
	(F.S.)	11	29	.50
9-95	Rocker shaft for key shift	11	29	1.20
$9-95\frac{1}{2}$ 9-100	Rocker shaft for key shift 20 Pl. Keyboard complete	1]	29	1.30
9-100	Keyboard complete 20 pl.	8	26 26	50.00
	Carriage case	1	23	23.50
9-5141	Carriage case 20 pl.	1 1 1	23	27.50
	Carriage crank handle	1	23	2.00
9-632	Repeat and non-repeat lever	11	29	.15
9-724	Subtraction gear & spider	9	27	
	16 Subtraction gear & spider 40 cycle 3 Subtraction gear & spider	9	27	1.75
9-797	25 & 50 cycle Start & stop switch	9	27	1.65
9-1220	Bottom keyboard plate	4 8	26	1.90
9-12201	Bottom keyboard plate 20 pl.	8	26	2.00
9-1233	L.H. lock ledge	1	23	.40
9-12331	L.H. lock ledge 20 pl.	1	23	.45
9-1260	Machine locator arm	3	24	1.25
9-1272	Cycle-stopping arm assembly	10	27	
9-1274	Stopping lever assembly	10	27	.85
9-1278 9-1281	Flexible end for over-carry trip Clutch yoke	10	27	2.75
9-1710	Keyboard top plate	8	26	3.25
	Keyboard top plate 20 pl.	8	26	4.00
	Carriage shifter rod and yoke	(no	t shown	

Mr. B. P. James, Toledo, Ohio.

				Assembly
08.				
82.				
88.				
08.				
.35			(See Bulletin 108A) Front arm for laten 14MK	
GT.			Assembly of gear on clearing orank	
08.			ung to first more tre smole to freeze,	
00.			Assembly of geer on R.H. end of hinge	85-9
1.40			rod	
			Assembly of gear on R.H. and of hinge	fa0-0
1.60	88		.iq OS bor	
00.			L.H. Minga rod bearing plate	9-24
84.			R.H. bings rod bearing plate	\$20-0
os.			Release laten for key shift (E.S.)	
			Huleago latch and arm for key shift	
08.			(2.8.)	
1.80			Rooker shaft for key shift	86-6
1.50			Rocker shaft for key shift 20 Pl.	\$89-9
00.08				
00.08			Meyboard complete 20 pl.	\$00I-6
00.53			Carriage case	0-014 V
102.78			Cerriage case 20 pl.	
00.3				
11			Toyel taegen-non bus tagged	
1.50			Subtraction gear & spider	787-0
dr.I			6 Bubtraction goar & spider 40 cycle	
			Bubtraction gear & spider	8/2 782-8
1.65	79		25 & 50 cycle	
11.00			Start & stop switch	164-6
00.1				0881-0
00.8			Bottom keyboard plate 20 pl.	10081-6
			D.H. lock lodge	8881-9
			L.H. lock ledge 20 pl.	9-1203}
700.1				
1.98				9-1272
88.		10		9-1274
34,	73		Flatible and for over-marry trip	
8.78			olov notice	
00.0			Reyboard top plate	0171-0
4.00		8 *	Reyboard top plate 20 pl.	9-171-0
1.30				Cx18-11